




# **Quick Guide QLEEN DISY Electro**

### 1. Assembly of hose reel

- 1.1 Push the hose reel in from right to left and lock it in place (Fig. 1)
- 1.2 Connect the blue hose on the side of the hose reel to the pure water output **1.2** (Fig. 2)
- 1.3 Roll out the hose to the required length
- 1.4 Disconnect the black connecting hose on the other side of the reel (Fig. 3)
- 1.5 Connect to the input of the drum 🖛 and the output for cleaning solution 🖛 (Fig. 3)




## 2. Connection water and power

- 2.1 Connect the water input (Fig. 4) to the house water connection using a Gardena hose,
- 2.2 alternatively connect the suction hose to the machine and sink the other side into the water tank
- 2.3 Open the water input of the house water connection
- 2.4 Plug in the mains plug (Fig. 4) → the control buttons (Fig. 5) 🖏 🐔 💽 light up blue

## 3. Bleeding

- 3.1 Open the bleeding tap (Fig. 4)
- 3.2 Switch on with the key  $(blue \Rightarrow green)$  and wait until water comes evenly out of the bleed (Fig. 4)
- 3.3 Switch off with the key (green  $\Rightarrow$  blue)
- 3.4 Place the suction hose for the cleaning solution (Fig. 4) into the cleaning solution tank
- 3.5 Set the dosing pump regulator (Fig. 5) to 100%
- 3.6 Switch on with the key (blue > green/turquoise) and wait until the key (blue > green continuously
- 3.7 Switch off with the key  $\sim$  (green  $\Rightarrow$  blue)
- **3.8** Attach the hose to the rod and brush bow or ROTAQLEEN, connect the cable for the ROTAQLEEN to the **ROTAQLEEN socket (Fig. 4)** and the ROTAQLEEN
- **3.9** The machine is ready for operation



#### 4. Cleaning with pure water

- **4.1** Switch on the machine with the key ( $\mathbb{F}_{4}$ ) (blue  $\Rightarrow$  green)
- 4.2 After a short time, the clean water arrives at the nozzles via the blue hose

#### 5. Cleaning with cleaning solution

- 5.1 Switch on the machine with the key → (blue ⇒ green), if the key → lights up turquoise dosing pump controller (Fig. 5) is set to 0 % and must be regulated high
- 5.2 After a short time, the cleaning agent solution arrives at the nozzles via the black hose.
- 5.3 The dosing quantity is adjusted with the dosing pump regulator (Fig. 5)

#### 6. Cleaning with tap water

- 6.1 Press the button  $\frown$  (blue / green  $\Rightarrow$  turquoise) for 2 seconds
- 6.2 The dosing pump is switched off, only tap water comes through the black hose.
- 6.3 Press the key  $\frown$  (turquoise  $\Rightarrow$  green) for 2 seconds to switch on the dosing pump again


#### 7. Control of the ROTAQLEEN

- **7.4** The ROTAQLEEN starts automatically in forward operation or last selected direction when pure water and/or cleaning solution/line water is switched on
- 7.5 To change the direction of the ROTAQLEEN, press the button (green ⇒ turquoise) and for back
  (turquoise ⇒ green)

#### Note: The machine can be controlled in parallel with the remote control in the same way

#### 8. Water quality meter (fig. 6)

- 8.1 Switch on with the Power button, the meter switches off automatically after 3 min
- 8.2 Press the IN button to measure the incoming water (the IN indicator lights up)
- 8.3 Press the OUT button to measure the outgoing clean water (the OUT indicator lights up)
- 8.4 We recommend to change the granulate at a value of 50  $\mu$ S



#### 9. After cleaning

- 9.1 Switch off the machine with the key (green ⇒ blue) and/or the key (turquoise / green ⇒ blue)
- 9.2 cleaning solution has been used:
  - Place the suction hose for cleaning solution (Fig. 4) in tap water
  - Set the dosing pump regulator (Fig. 5) to 100%.
  - Switch on with the key <a>(blue ⇒ green) and rinse the dosing pump for 2 min</a>
  - Then switch off the machine with the key 🛹 (green ⇒ blue)
- 9.3 Pull out the mains plug (Fig. 4), close the water supply and disconnect the connection.
- 9.4 Reel up the hose and dismantle the hose reel

## Karlhans Lehmann KG, Kranichstraße 2a, DE -17235 Neustrelitz

Homepage:	www.qleen.de
Phone:	+49 (0)3981 48850
E-Mail:	info@qleen.de